

UNCLASSIFIED

AD NUMBER

ADB119415

LIMITATION CHANGES

TO:

Approved for public release; distribution is unlimited.

FROM:

Distribution authorized to U.S. Gov't. agencies only; Test and Evaluation; FEB 1988. Other requests shall be referred to Commander, US Army Dugway Proving Ground, ATTN: STEDP-SD-TA, Dugway, UT 84022-5000.

AUTHORITY

ECBC memo dtd 14 Oct 2014

THIS PAGE IS UNCLASSIFIED



AD _____
RDT& PROJECT NO. 1-M-465710DO49
TECOM PROJECT NO. 8-CO-210-049-090
DPG DOCUMENT NO. DPG/TA-88/07



U.S. ARMY
MATERIEL COMMAND

DTIC FILE COPY

TECHNICAL REPORT

AD-B119 415

**RELIABILITY OF M256 CHEMICAL AGENT DETECTOR KIT
AT EXTREME ENVIRONMENTAL TEMPERATURES**

by

C.K. Ramachandran

February 1988

**DTIC
ELECTE
MAR 3 0 1988
S E D**

Distribution authorized to U.S. Government agencies only: Test and Evaluation (Feb 88). Other requests for this document shall be referred to: Commander, U.S. Army Dugway Proving Ground, ATTN: STEDP-SD-TA, Dugway, UT 84022-5000

**TECHNICAL ANALYSIS AND INFORMATION OFFICE
U.S. ARMY DUGWAY PROVING GROUND
Dugway, Utah 84022-5000**

DISPOSITION INSTRUCTIONS

Destroy this document when no longer needed; do not return to originator.

DESTRUCTION NOTICE

For unclassified limited documents, destroy by any method that will prevent disclosure of contents or reconstruction of the document.

DISCLAIMER STATEMENT

The findings in this document are not to be construed as an official Department of the Army position unless so designated by other authorized documents. The use of trade names does not constitute an official endorsement or approval of the use of such commercial hardware or software. This document may not be cited for purposes of advertisement.

REPORT DOCUMENTATION PAGE

1a. REPORT SECURITY CLASSIFICATION UNCLASSIFIED			1b. RESTRICTIVE MARKINGS AD-8119 413L	
2a. SECURITY CLASSIFICATION AUTHORITY			3. DISTRIBUTION/AVAILABILITY OF REPORT Authorized to U.S. Government agencies only (T&E, FEB 88); other requests for this document shall be referred to OIR DRG (STEDP-SD-TA).	
2b. DECLASSIFICATION/DOWNGRADING SCHEDULE				
4. PERFORMING ORGANIZATION REPORT NUMBER(S) DFG/TA-88/07			5. MONITORING ORGANIZATION REPORT NUMBER(S)	
6a. NAME OF PERFORMING ORGANIZATION Technical Analysis and Information Office		6b. OFFICE SYMBOL (if applicable) STEDP-SD-TA	7a. NAME OF MONITORING ORGANIZATION	
6c. ADDRESS (City, State, and ZIP Code) U.S. Army Dugway Proving Ground Dugway, Utah 84022-5000			7b. ADDRESS (City, State, and ZIP Code)	
8a. NAME OF FUNDING/SPONSORING ORGANIZATION		8b. OFFICE SYMBOL (if applicable)	9. PROCUREMENT INSTRUMENT IDENTIFICATION NUMBER	
8c. ADDRESS (City, State, and ZIP Code)			10. SOURCE OF FUNDING NUMBERS	
			PROGRAM ELEMENT NO. 1MA657	PROJECT NO. 10DO49
11. TITLE (Include Security Classification) Reliability of M256 Chemical Agent Detector Kit at Extreme Environmental Temperatures				
12. PERSONAL AUTHOR(S) Ramachandran, C.K.				
13a. TYPE OF REPORT Technical		13b. TIME COVERED FROM Current TO		14. DATE OF REPORT (Year, Month, Day) 1988 February
15. PAGE COUNT 13				
16. SUPPLEMENTARY NOTATION				
17. COSATI CODES			18. SUBJECT TERMS (Continue on reverse if necessary and identify by block number)	
FIELD 15	GROUP 02	SUB-GROUP	Chemical warfare, chemical agent detection, nerve agent, blister agent, blood agent, M256 detector kit, M256AF detector kit, chemical warfare in extreme temperatures	
19. ABSTRACT (Continue on reverse if necessary and identify by block number)				
<p>The M256 chemical agent detector kit is used to detect and classify hazardous concentrations of nerve, blister, and blood agents in vapor and liquid states. This device has been tested and shown to be reliable in a wide range of climatic conditions. However, at extreme cold temperatures, the kit needs to be kept warm to ensure that all of the reagents are in a liquid state. In hot climates, the evaporation of the reagents can become a problem especially when the wind velocity is high.</p> <p>Instruction on the use of the M256 kit under extreme temperatures are given in Operator's Manual, TM 3-6665-307-10 (September 1985). The instructions given in FM 3-4 to discard the frozen kit is wrong. The kits can be used after they are thawed.</p> <p><i>Keywords:</i></p>				
20. DISTRIBUTION/AVAILABILITY OF ABSTRACT <input type="checkbox"/> UNCLASSIFIED/UNLIMITED <input type="checkbox"/> SAME AS RPT. <input type="checkbox"/> DTIC USERS			21. ABSTRACT SECURITY CLASSIFICATION UNCLASSIFIED	
22a. NAME OF RESPONSIBLE INDIVIDUAL C.K. Ramachandran			22b. TELEPHONE (Include Area Code) (801) 831-3371	22c. OFFICE SYMBOL STEDP-SD-TA

FOREWORD

This study was prepared in compliance with the requirements of RDTE Project 1M465710D049, and deals with the reliability of the M256 Chemical Agent Detector Kit under potential operational environments. A brief description of the chemical reactions involved in the detection mechanism is included for general information.

The report was prepared by Chittoor K. Ramachandran, Technical Analysis and Information Office, U.S. Army Dugway Proving Ground, Utah. The author wishes to thank Dr. David R. Browning of Bendix Environmental Systems, Dr. Robert Eckhaus of United States Army Chemical Research and Development Center and Dr. Kenneth S.K. Chinn of the Technical Analysis Office, Dugway Proving Ground for their invaluable help.

Comments and suggestions regarding the adequacy or accuracy of the contents of this document should be addressed to Commander, U.S. Army Dugway Proving Ground, ATTN: STEDP-SD-TA, Dugway, UT 84022, AV 789-3371.

Accession For	
NTIS GRA&I	<input type="checkbox"/>
DTIC TAB	<input checked="" type="checkbox"/>
Unannounced	<input type="checkbox"/>
Justification	
By	
Distribution/	
Availability Codes	
Dist	Avail and/or Special
B-3	



TABLE OF CONTENTS

	Page No.
FOREWORD	i
LIST OF TABLES AND FIGURES	iv
1 INTRODUCTION.....	1
2 EVALUATION OF THE M256 KIT.....	1
2.1 GENERAL DESCRIPTION.....	1
2.2 CHEMICAL REACTIONS.....	4
2.3 ENVIRONMENTAL TESTING.....	4
2.4 OPERATION OF M256 KIT UNDER EXTREME TEMPERATURE.....	5
3 CURRENT STATUS OF CHEMICAL AGENT DETECTION.....	8
4 REFERENCES.....	10

LIST OF TABLES AND FIGURES

<u>Table</u>	<u>Page No.</u>
1 Chemical Warfare Agent Detectable by the M256 Kit.....	2
2 Performance of the M256 Kit in a Desert Environment.....	6
3 Performance of the M256 Kit in a Tropical Environment.....	7
4 Reliability of the M256A1 (M256E1) Kit.....	9

<u>Figure</u>	
1 M256 Chemical Agent Detector Kit (Front View).....	3
2 Sampler - Detector (Protective Bag Removed).....	3

1. INTRODUCTION

In battles involving chemical warfare (CW) agents, detection and identification of the agents in the environment is essential. Although protective garments and masks can provide soldiers with adequate protection, they drastically hamper the soldiers' normal operations. It is therefore advisable to determine whether CW agents are present in the environment so that the soldier can assume a protective posture appropriate for the situation. The current method of detecting chemical agents is by the use of the M256 chemical agent detector kit (M256 Kit), which identifies blister, nerve, and blood agents.

The M256 kit is crucial for the operation of the combat force in a chemically contaminated environment. Since this device is used primarily as an "all clear" indicator, if it fails to detect the agents present in the environment, casualties can ensue. On the other hand, a false positive indication will cause the needless burden of assuming a protective posture that will reduce the efficiency of the soldier. Also, since exposure for long periods to chemicals in sublethal amounts can be hazardous, periodic monitoring using the M256 kit is essential following a chemical attack.

In compliance with the requirement of RDTE Project IM465710D049, this study was undertaken to investigate the effect of exposure of the M256 kit to extreme climatic conditions on its sensitivity and reliability in detecting CW agents. Such information was warranted mainly because the climatic condition and the terrain at which the U.S. soldiers may have to confront a chemical attack remains uncertain. Since detection is based on chemical reactions between the CW agents and the specific reagents provided in the 'ready to use' ampoules of the kit, a brief review of the chemical reactions involved is given in this report. Detailed information on the chemistry and the engineering aspects of the kit are available in References 1 and 2.

2. EVALUATION OF THE M256 KIT

2.1 GENERAL DESCRIPTION

The M256 kit has two components, a booklet of M8 paper (ABCVGH-M8), which detects liquid chemical agents, and a sampler/detector, which is designed to detect and identify agent vapors. This report will discuss only the vapor detection mechanism. The sampler/detector part of the kit has been designed to detect three main classes of CW agents. Table I lists the agent vapor that can be detected by the device.

The packaged reagents are premixed in finger-crushable glass ampoules and the individual tests are carried out at designated spots on the sampler discs. Figures 1 and 2 show the design of the kit. The layout of the sampler/detector is noteworthy in that special care has been taken to avoid interference between the tests for various agents. Since the detection mechanism of the kit is based on chemical and enzymatic reactions, a brief examination of the reactions is pertinent.

TABLE 1. Chemical Warfare Agents Detectable by the M256 Kit

Agent	Detectable Concentration (mg/m ³)
<u>Nerve</u>	
VX	0.10 \pm 0.02
G	0.05 \pm 0.01
<u>Blood</u>	
Hydrogen Cyanide (AC)	9.0 \pm 2.0
Cyanogen Chloride (CK)	9.0 \pm 2.0
<u>Blister</u>	
Lewisite (L)	9.0 \pm 5.0
Mustard (H)	2.0 \pm 1.0
Phosgene Oxime (CX)	---




Figure 1. M256 Chemical Agent Detector Kit (front view). Reproduced from TM 3-6665-307-10.




Figure 2. Sampler - Detector (protective bag removed). Reproduced from TM 3-6665-307-10.

2.2 CHEMICAL REACTIONS

a. Nerve Agents

The M256 kit detects G and V agents by taking advantage of the competition of these agents for the active site of the enzyme acetylcholinesterase with the substrate 2,6-dichlorophenol acetate (2,6-DIPA). In the absence of nerve agent, acetylcholinesterase (immobilized on a filter paper spot) converts 2,6-DIPA into 2,6-dichlorophenol, a compound that is blue in color. If either G or V agent is present it will tie up the enzyme, which will then not be available to react with 2,6-DIPA to form the blue color. The test is carried out on the filter paper spot. Tris buffer and 2,6-DIPA are provided in two separate ampoules.

b. Blood Agents

A pink or blue color complex is formed when CK (cyanogen chloride) reacts with 4-benzylpyridine and barbituric acid. If the agent AC (hydrogen cyanide) is present, it is converted to CK by the sodium hypochlorite solution provided in one of the ampoules. In the sampler/detector, the reaction test spot is impregnated with barbituric acid, and the 4-benzylpyridine is provided in an ampoule. When the reagents are mixed, the color change indicates the presence of CK or AC in the air. In the absence of the agents, the test spot remains colorless.

c. Blister Agents

Mustard gas (H) can be detected because of its reaction with a methanolic solution of DB-3 [4-(4'-nitrobenzyl)pyridine] in the presence of a catalyst, mercuric cyanide. The product of this reaction then reacts with potassium carbonate to form an intense blue-purple color. A similar reaction occurs when phosgene oxime (CX) is present, the final color being pink or red. Both of these reactions are faster at elevated temperatures; therefore, a chemical heating component (cupric chloride and aluminum powder) is included in the kit.

d. Lewisite

The test for lewisite involves the reaction between lewisite and Michler's thioketone [4,4-bis (dimethylamino)thiobenzophenone]. The reagent is immobilized in an inert carrier and extruded into a crayon. The crayon when smeared into a white background turns olive-drab green when lewisite is present.

2.3 ENVIRONMENTAL TESTING

The design and sensitivity of the chemical reactions of the M256 kit have been subjected to a number of tests, and tests were used in making modifications. The problems encountered during the developmental stages of the kit are summarized by Turner et al. (Ref. 2). These aspects are beyond the scope of this report and therefore not discussed.

In a study conducted at Yuma Proving Ground (Ref. 3), M256 kits were subjected to a 90-day field-carry test; the samplers were then challenged with either CW agent or a control substitute at hot and humid conditions. Tests to measure the responses to each agent were then carried out. The results are given in Table 2. The samplers responded properly to all CW agents. All responses were negative for the control tests. From this test it was concluded that at intermediate hot-dry (52°C) conditions, the M256 kit is reliable.

In a separate study conducted by U.S. Army Dugway Proving Ground (Ref. 4), 90-day field-carried kits (at Tropic Test Center) were exposed to hot-wet conditions. The results are presented in Table 3. Sampler response was examined when the temperature was 35°C and the relative humidity, 74 percent. All of the samplers showed proper responses indicating that at this environmental condition, the M256 kit is reliable.

A test on the operation of the M256 kit was also carried out in cold weather conditions (the temperature ranged from -38 to 9°C) (Ref. 5). It was noticed that false-positive nerve agent responses could occur when the atmospheric temperature was -9°C or below. Several ampoules were frozen when stored at -20°C. Although at cold temperatures the immobilized acetylcholinesterase (on the reaction pad) was stable, a decrease in the enzyme activity may be expected.

2.4 OPERATION OF M256 KIT UNDER EXTREME TEMPERATURE

The reliability of the M256 kit appears to be good at high environmental temperatures. However, one needs to be cautious in using the kit at an extremely hot, dry condition, for example in the Middle East where high winds can be associated with the high temperature. The liquid reagents are essential for the color development (for a period of about 20 minutes); however, wind will cause the reagents to evaporate quickly. This problem may be minimized by placing the kit in an open box protected from direct wind.

As indicated, cold temperatures can adversely affect the M256 kit. The arctic wind can bring the temperature substantially below the freezing point of the reagents and impair the use of the kit.

In the technical manual (TM) for Chemical Agent Detector Kit, M256 (TM 3-6665-307-10-Ref. 6), information concerning low temperature operation is as follows:

"When the temperature is below freezing, the sealed protective bag containing the samples must be warmed (in a shelter, vehicle, or within the operator's clothing) until the liquid reagents in the ampoules are no longer frozen. After the bags are opened and examined, the samples are warmed again in the operator's clothing without contaminating it. If the temperature is below 50 F (10°C) wait for five minutes before reading the color. Wait for two minutes after conducting tests to observe color comparison."

The recently revised TM (TM 3-6665-307-10-Ref.7) also instructs that frozen reagents have to be thawed completely before the kit is used.

TABLE 2. PERFORMANCE OF THE M256 KIT IN A DESERT ENVIRONMENT^a

90-Day Carry Test Environment	Agent	Agent Conc. (mg/m ³)	Tempera- ture (°C)	Relative Humidity (%)	Proportion Responding Properly	Reliability of Response (%)	
						50% Confidence Interval	90% Confidence Interval
Yuma Proving Ground	GB	0.011	52	18	27/27	97.4-100	91.8-100
	VX	0.06	52	19	27/27	97.4-100	91.8-100
	HD	2.0	52	19	27/27	97.4-100	91.8-100
	CX	2.0	52	23	27/27	97.4-100	91.8-100
	AC	8.8-9.0	52	23	27/27	97.4-100	91.8-100
	L	4.0	52	23	27/27	97.4-100	91.8-100
	Blanks	None	52	20	27/27	97.4-100	91.8-100

^aThe samplers were challenged under the indicated temperature and relative humidity for 10 minutes. Each reaction was carried out to examine the performance of the kit. The data are taken from Zylstra (Ref. 3).

TABLE 3. PERFORMANCE OF THE M256 KIT IN A TROPICAL ENVIRONMENT

90-Day Carry Test Environment	Agent	Agent Conc. (mg/m ³)	Tempera- ture (°C)	Relative Humidity (%)	Proportion Responding Properly	Reliability of Response (%)	
						50% Confidence Interval	90% Confidence Interval
Tropic Test Center	GB	0.05	35	74	27/27	97.4-100	91.8-100
	VX	0.10	35	75	27/27	97.4-100	91.8-100
	HD	2.5	35	72	27/27	97.4-100	91.8-100
	CX	3.0	35	74	17/17 ^a	96.0-100	87.3-100
	AC	11.0	35	74	27/27	97.4-100	91.8-100
	L	11.0	35	74	26/27	97.3-100	91.5-100
	Blanks	None	35	71/73 ^b	27/27	97.4-100	91.8-100

NOTE: After being carried for 90 days in a tropical environment, the samplers were exposed to the indicated temperature and humidity in a chamber and challenged with the agents for 10 minutes. Tests were carried out to examine the performance of each reaction. The data are taken from Zylstra (Ref. 4).

^aOnly 17 samplers were tested with CX because of ampoule breakage, which limited the number of available components.

^bBlister components were functional at 71 percent relative humidity, and 11 other components were functional at 73 percent relative humidity.

however, the instructions given in a recently published field manual (FM 3-4) on NBC Protection are somewhat misleading. Field Manual 3-4 (Ref. 6) emphasizes the need to take special precautions when the M256 kit has to be used in arctic weather where temperatures can be very low. It instructs: "(when the temperature is -15°F (-26°C) or below), the solutions in the capsules freeze, and the solutions will not work even if reheated." This statement places severe restrictions on the use of M256 kit in cold weather. It also contradicts the instructions given in the technical manual (Ref. 7). In the environmental tests carried out prior to the type classification of this kit (Ref. 5), no impairment in the function was noticed following exposure to extreme cold weather. Therefore, the instruction given in FM 3-4 is not correct. It is recommended that appropriate changes be made in FM 3-4 on page B-3.

The technical manual (Ref. 7) cautions that at a high temperature and low humidity (desert conditions), the nerve agent spot may dry up and it is therefore necessary to rewet the spot by squeezing ampoule 3 to deliver a few more drops of the buffer.

At a high temperature and high humidity (tropic) conditions, the color produced by lewisite may be very faint. Therefore, before a judgement is made, this test should be repeated. Also, under tropic conditions a faint blue color may appear even in the absence of the blister agent (Ref. 7).

3. CURRENT STATUS OF CHEMICAL AGENT DETECTION

The M256 kit has been subjected to a number of tests and many alterations in the engineering and the detection procedures have been made to make this kit as reliable as possible. The environmental condition that will most impair its function in detecting nerve agents is extreme cold weather. However, because the primary use of the kit is as an "all clear" indicator rather than as a warning sign, the soldiers should have time to bring the kit to a warm temperature before the test is done. Moreover, the testing can be repeated to confirm the results.

A critical evaluation of the usefulness of M256 kit is warranted. As the test is based on the color reactions and visual judgement, human error is possible. This is especially true in night-time operations. In addition, color blind soldiers may find it difficult to use this kit.

Although the Army has accepted the M256 kit, the kit has not met several of the original requirements for the detection of VX, as stated in the material needs (see Ref. 8). Studies have shown that miosis could occur at nerve agent concentrations below the VX detection levels of the kit. Recently, with the use of eel acetylcholinesterase, the sensitivity of the improved version of the M256 (M256A1, during experimental stages the kit was named M256E1) can detect concentrations of G agent at 0.005 mg/m^3 and of VX at 0.013 mg/m^3 without making any change in the original design. Table 4 provides some features on the reliability of the M256A1 kit. As the data indicate, the M256A1 kit should be reliable even when exposed to battlefield contaminants and does not give a false alarm even at extreme temperatures.

TABLE 4 RELIABILITY OF THE M256A1 (M256E1) KIT

Test Conditions	Number Trials	Correct Response	Reliability	Confidence
1. Blank ^a , ambient (68°F), accelerated aging	50	50	95.5	90
2. Blank, cold (33°F), accelerated aging				
a. Response time - 5 min	50	44	80.0	90
b. Response time - 5 min	50	48	90.0	90
3. Blank, interferent, accelerated aging				
a. HC smoke	65	64	94.1	90
b. Burning brush	48	48	95.3	90
c. Sevin	50	50	95.5	90
4. VX, 018 mg/m ³ ambient (110 F), unaged	33	33	93.3	90

^aNo agent present
Data taken from Reference 7.

References

1. Browning, David A. Development of the XM256 Chemical Agent Detector Kit. Prepared by The Bendix Corporation, Contract DAAA15-74-U237 for U.S. Army Armament Research and Development Command, Aberdeen Proving Ground, Maryland, December 1977.
2. Turner, R.B., et al. Engineering Development of the M256 Chemical Agent Detector Kit. Technical Report ARCSL-TR-79012, U.S. Army Armament Research and Development Command, Aberdeen Proving Ground, Maryland, December 1977.
3. Zylstra, D.R. Letter Report, Desert Phase of DT 11 (Environmental) Test of the XM256 Chemical Agent Detector Kit. DPG-LR-76-202-3, U.S. Army Dugway Proving Ground, Dugway, Utah, April 1979.
4. Zylstra, D.R. Letter Report Of Tropic Phase of DT 11 (Environmental) Test of the XM256 Chemical Agent Detector Kit. DPG-LR-76-202-2, U.S. Army Dugway Proving Ground, Dugway, Utah, June 1978.
5. Zylstra, D.R. Letter Report of Cold Regions Phase of DT 11 (Environmental) and Agent Challenge of XM256 Kits for DT 11 Test. DPG-LR-76-202-1, U.S. Army Dugway Proving Ground, Dugway, Utah, February 1978.
6. Operator's Manual, Detection Kit, Chemical Agent: M256. TM 3-6665-307-10, January 1979.
7. Operator's Manual, Chemical Agent Detector Kit and M256A1. TM 3-6665-307-10, September 1985.
8. Brice, B.A. Independent Evaluation Report for the M256 E1, Chemical Agent Detector Kit, (Product Improvement Project). U.S. Army Test and Evaluation Command, Aberdeen Proving Ground, Maryland, October 1984, AD-C035.668. (Classified Secret)
9. Field Manual 3-4, NBC Protection. Headquarters, Department of the Army, Washington, DC, October, 1985.

PROJECT DO49 DISTRIBUTION LIST

OFFICE OF THE SECRETARY OF DEFENSE
OATS(DAE) (CHEMICAL MATTERS)
WASHINGTON, DC 20301

DEPARTMENT OF DEFENSE
OUSDRE(ELS)
ROOM 3/D129, PENTAGON
WASHINGTON, DC 20301

ORGANIZATION OF JOINT CHIEFS OF STAFF
ATTN: J-3 JOD (LTC TRIPLER)
WASHINGTON, DC 20301

ORGANIZATION OF JOINT CHIEFS OF STAFF
CHIEF, CHEMICAL WARFARE BRANCH
NUCLEAR AND CHEMICAL DIV (J-5)
WASHINGTON, DC 20301

DIRECTOR
DEFENSE INTELLIGENCE AGENCY
ATTN: DT-5A
DX-7B
DB-4G1
DB-1B2
WASHINGTON, DC 20301

DIRECTOR
ARMED FORCES MEDICAL INTELLIGENCE CENTER
ATTN: AFMIC-ZA
FORT DETRICK, FREDERICK, MD 21701

STATE DEPARTMENT
ATTN: INR (MR. CROCKER)
WASHINGTON, DC 20520

DIRECTOR
CENTRAL INTELLIGENCE AGENCY
ATTN: OSWR
WASHINGTON, DC 20506

COMMANDER IN CHIEF
U.S. EUROPEAN COMMAND
ATTN: ECJ5-N
APO NEW YORK 09128

COMMANDER IN CHIEF PACIFIC
ATTN: J5414 (BOX 15)
CAMP SMITH, HI 96861

COMMANDER IN CHIEF
U.S. ATLANTIC FLEET
ATTN: J338 (LTC MILES)
NORFOLK, VA 23511

COMMANDER IN CHIEF
U.S. SOUTHERN COMMAND
ATTN: SCJ3
APO MIAMI, FL 34004

COMMANDER IN CHIEF
U.S. CENTRAL COMMAND
ATTN: CCJ3-X (MAJOR ROSS)
MACDILL AFB, FL 33608-7001

COMMANDER IN CHIEF
U.S. SPECIAL OPERATIONS COMMAND
ATTN: SOJ3-05
MACDILL AFB, FL 33608

COMMANDER
U.S. FORCES KOREA
ATTN: CJ-PL-N
APO SAN FRANCISCO 96301

COMMANDER
U.S. FORCES JAPAN
ATTN: J3
APO SAN FRANCISCO 96328

* * * * *

HQDA (SARD-ZCS)
ATTN: (MAJ SERGIO)
WASHINGTON, DC 20310-0643

HQDA (DAMO-SWC)
ATTN: LTC BROWN
DR. ROBERT E. BOYLE
WASHINGTON, DC 20310-0102

HQDA (DASG-HCD-D)
ATTN: CPT ENG
5109 LEESBURG PIKE
FALLS CHURCH, VA 22041-3258

COMMANDER IN CHIEF
U.S. ARMY EUROPE
ATTN: AEAGC-NC-C
APO NEW YORK 09403

U.S. ARMY MATERIEL COMMAND
ATTN: AMCCN-M (MR. KOGER)
AMCCN-C
5001 EISENHOWER AVE
ALEXANDRIA, VA 22333-0001

COMMANDER
U.S. ARMY TEST AND EVALUATION COMMAND
ATTN: AMSTE-TE-T
AMSTE-TE
ABERDEEN PROVING GROUND, MD 21005

COMMANDER
U.S. ARMY TRAINING AND DOCTRINE COMMAND
ATTN: ATCD-N
ATCD-T
FORT MONROE, VA 23651

COMMANDER
U.S. ARMY FORCES COMMAND
ATTN: AFOP-TN
FORT MCPHERSON, GA 30330

COMMANDER
U.S. ARMY MEDICAL RESEARCH AND
DEVELOPMENT COMMAND
ATTN: SGRD-PL
FORT DETRICK, FREDERICK, MD 21701-5012

COMMANDER
U.S. ARMY MEDICAL RESEARCH INSTITUTE
OF CHEMICAL DEFENSE
ATTN: SGRD-UV-RO
ABERDEEN PROVING GROUND, MD 21010-5425

COMMANDER
U.S. ARMY AVIATION SYSTEMS COMMAND
ATTN: AMCPM-ALSF-D (LTC GRIFFIN)
4300 GOODFELLOW BOULEVARD
ST. LOUIS, MO 63120

COMMANDER
U.S. ARMY WESTERN COMMAND
ATTN: APOP-NC
APLG-MU
FORT SHAFTER, HI 96858

COMMANDER
U.S. ARMY LOGISTICS CENTER
ATTN: ATCL-MN
FORT LEE, VA 23801

COMMANDER
CHEMICAL RESEARCH, DEVELOPMENT
AND ENGINEERING CENTER
ATTN: SMCCR-TD
SMCCR-ST
SMCCR-RSP
SMCCR-PPD
SMCCR-SPS-IL
SMCCR-OPR (P. SLYGH)
TECHNICAL LIBRARY
ABERDEEN PROVING GROUND, MD 21010

U.S. ARMY COLD REGION RESEARCH
AND ENGINEERING LABORATORY
ATTN: LOUISE V. PARKER
HANOVER, NH 03755

COMMANDER
U.S. ARMY TRADOC
ATTN: ATZL-TIE
FORT LEAVENWORTH, KS 66027-5130

COMMANDER
U.S. ARMY TRANSPORTATION CENTER
AND FORT EUSTIS
ATTN: ATSP-PD-C (CHEMICAL OFFICER)
FORT EUSTIS, VA 23804

COMMANDER
U.S. ARMY AVIATION CENTER
ATTN: ATZQ-D-MS
FORT RUCKER, AL 36362

COMMANDER
U.S. ARMY INTELLIGENCE AND THREAT
ANALYSIS CENTER
ATTN: AIAIT-WT, BLDG 203, STOP 314
WASHINGTON NAVY YARD
WASHINGTON, DC 20374

COMMANDER
U.S. ARMY FOREIGN SCIENCE
AND TECHNOLOGY CENTER
ATTN: AIAST-RA-ID1 (MR. GOLDBERG)
220 SEVENTH STREET NE
CHARLOTTESVILLE, VA 22901

COMMANDER
U.S. ARMY MEDICAL RESEARCH INSTITUTE
OF INFECTIOUS DISEASES
FORT DETRICK, FREDERICK, MD 21701

COMMANDER
U.S. ARMY NATICK RESEARCH, DEVELOPMENT
AND ENGINEERING CENTER
ATTN: STRNC-AC (MR. MALABARBA)
STRNC-I (MR. WAJDA)
STRNC-U (MR. ALVES)
STRNC-YA (DR. HERZ)
STRNC-W (MR. MILLER)
NATICK, MA 01760

COMMANDER, USAJFKSWC
ATTN: ATSU-CD-CS (MAJ FUNDERBURG)
FORT BRAGG, NC 28307-5000

DIRECTOR
U.S. ARMY MATERIEL SYSTEMS
ANALYSIS ACTIVITY
ATTN: AMXSY-CR
ABERDEEN PROVING GROUND, MD 21005-5071

DIRECTOR
U.S. ARMY BALLISTIC RESEARCH LABORATORY
ATTN: AMDAR-BLV=R/BDP (DR. WICK)
ABERDEEN PROVING GROUND, MD 21005

PRESIDENT
U.S. ARMY AIRBORNE BOARD
ATTN: ATXA-BDT/BDP
FORT BRAGG, NC 28307

COMMANDER
U.S. ARMY CHEMICAL SCHOOL
ATTN: ATZN-CM-NF (MAJOR EVANS) (25 copies)
FORT MCLELLAN, AL 36205

COMMANDER
U.S. ARMY ARMOR & ENGINEER BOARD
ATTN: ATZK-AE-TR
FORT KNOX, KY 40121-5470

COMMANDANT
ACADEMY OF HEALTH SCIENCES
ATTN: HSA-CDB
FORT SAM HOUSTON, TX 78234

COMMANDER
JOINT TASK FORCE FOR IMPROVEMENT OF
CHEMICAL CAPABILITY
ATTN: CSTE-CHEMCAP
5600 COLUMBIA PIKE
FALLS CHURCH, VA 22041-5115

COMMANDER
U.S. ARMY OPERATIONS TEST AND
EVALUATION AGENCY
ATTN: CSTE-CS (LTC UPTON)
5600 COLUMBIA PIKE
FALLS CHURCH, VA 22041-5115

PRESIDENT
U.S. ARMY COMMUNICATIONS AND
ELECTRONICS BOARD
ATTN: ATZH-BD
FORT GORDON, GA 30905

COMMANDER
U.S. ARMY NUCLEAR AND CHEMICAL AGENCY
ATTN: MONA-NU
MONA-CM (MR. MCGEE)
MONA-WE
MONA-SAL
7500 BACKLICK ROAD (BLDG 2073)
SPRINGFIELD, VA 22150

COMMANDER
U.S. ARMY TANK AUTOMOTIVE COMMAND
ATTN: AMSTA-NR (LTC NOTEBLOOM)
WARREN, MI 48397-5000

DETACHMENT 63
INDIAN HEAD, MD 20640-5099

COMMANDER
U.S. ARMY DEVELOPMENT
AND EMPLOYMENT AGENCY
ATTN: MODE-FSD-SV (MAJ WILSON)
FORT LEWIS, WA 98433-5000

COMMANDER
U.S. ARMY TRADOC SYSTEMS
ANALYSIS AGENCY
ATTN: ATOR-TDB
WHITE SANDS MISSILE RANGE, NM 88002

PRESIDENT
U.S. ARMY ARMOR AND ENGINEER BOARD
ATTN: ATZK-AE-TR
FORT KNOX, KY 40121-5470

COMMANDANT
U.S. ARMY AVIATION LOGISTICS SCHOOL
ATTN: ATSQ-CDM (CPT BLASE)
FORT EUSTIS, VA 23604

5TH SPECIAL FORCES GROUP (A)
ATTN: AFVX-SFA-NBC
FORT BRAGG, NC 28307

1ST SPECIAL OPERATIONS COMMAND
(AIRBORNE)
ATTN: AFVX-GC-NBC (MAJ WOJCICKI)
FORT BRAGG, NC 28307

COMMANDANT
U.S. ARMY FIELD ARTILLERY SCHOOL
ATTN: ATSF-CD-W (2 copies)
FORT SILL, OK 73503

COMMANDANT
U.S. ARMY INFANTRY SCHOOL
ATTN: ATSH-CD-MLS-C (2 copies)
FORT BENNING, GA 31905

* * * * *

HQ USAF
ATTN: XOORB
XOXFM
WASHINGTON, DC 20330

HQ USAF
ATTN: DEK
DOQ
APO NEW YORK 09012-5001

HQ PACAF
ATTN: DOX
XPX
HICKAM AFB, HI 96853-5001

HQ AFIS/INKTC
WASHINGTON, DC 20330-5110
HQ SAC
ATTN: XPHV (MR. STRUCK)
DO8X
OFFUTT AFB, NE 68113-5001

HQ MAC
ATTN: XOND (MAJ STEINER) (4 copies)
XPQ
SGPB
SCOTT AFB, IL 62225-5001

HQ TAC
ATTN: DRP
DOXS
LGW
LANGLEY AFB, VA 23665-5001

HQ AFRES/DOH
ROBINS AFB, GA 31098-6001

USAFALCENT/TE
ATTN: MAJ MILLER
POPE AFB, NC 28308-5000

HQ ESC/DOM
KELLY AFB, TX 78243-5000

HQ AF SPACE COMMAND
ATTN: DOC
PETERSON AFB, CO 80914-5001

COMMANDER
HQ ALASKA NORAD REGION
ATTN: AAC/DOSN
ELMENDORF AFB, AK 99506-5000

HQ AFSC
ATTN: SGB
TEV
TEOX
ANDREWS AFB, MD 20334-5000

HQ ANGSC/DOS
ANDREWS AFB, MD 20331-6008

HQ AFTEC/TEL
KIRTLAND AFB, NM 87117

HQ AFCC/CFSR
SCOTT AFB, IL 62225-5001

HQ NORAD/j31CN
CHEYENNE MOUNTAIN COMPLEX, CO 80914-5061

HQ AFIS/INT
BOLLING AFB, DC 20332

HQ ATC/DORD
RANDOLPH AFB, TX 78150-5001

USAF TAWS/THLO
EGLIN AFB, FL 32542

AD/YO
EGLIN AFB, FL 32542

HQ ASD
ATTN: AES
XRM
EN
WRIGHT-PATTERSON AFB, OH 45433

HQ AFLC
ATTN: LOC
XOW
WRIGHT-PATTERSON AFB, OH 45433-5001

COMMANDING GENERAL WRIGHT-PATTERSON AFB
AFAMRL/HE (CLYDE REPLOGLE)
DAYTON, OH 45433

FTD/NISS (TQTR)
ATTN: SHERRY JENNINGS
WRIGHT-PATTERSON AFB, OH 45433

AMD/RDSM
AMD/RDTK
AMD/RDSX
BROOKS AFB, TX 78235

AFDPRC/PR
LOWRY AFB, CO 80238-5000

COMMANDER
23RD AIR FORCE
ATTN: DOXP
HURLBURT, FL 32542-5000

COMMANDER
AIR FORCE SPECIAL OPERATIONS SCHOOL
HURLBURT, FL 32542-5000

USAFSAM/VNC
BROOKS AFB, TX 78235

3460 TCHTG/TTMTD
LOWRY AFB, TX 78235

* * * * *

OFFICE OF CHIEF OF NAVAL OPERATIONS
ATTN: OP-703E (LT CDR STRIDE)
WASHINGTON, DC 20350

COMMANDER IN CHIEF
U.S. NAVY EUROPE
ATTN: N5
FPO NEW YORK 09510-0151

BUREAU OF MEDICINE AND SURGERY
CODE 5512, ROOM 7801, BLDG 7
NAVY DEPARTMENT

WASHINGTON, DC 20372

COMMANDER IN CHIEF PACIFIC FLEET
PEARL HARBOR, HI 96860

NAVAL AIR SYSTEMS COMMAND HQ
ATTN: AIR (MR. MANYAK)
WASHINGTON, DC 20361

COMMANDER
NAVAL SPECIAL WARFARE CENTER
CORONADO, CA 92155-5000

NAVAL SEA SYSTEMS COMMAND
ATTN: SEA 05R (DR. GLORIA PATTON)
WASHINGTON, DC 20362-5101

COMMANDER NAVAL AIR FORCE
U.S. PACIFIC FLEET
NAVAL AIR STATION, NORTH ISLAND
SAN DIEGO, VA 92135

COMMANDER NAVAL SURFACE FORCE
U.S. PACIFIC FLEET
NAVAL AMPHIBIOUS BASE CORONADO
SAN DIEGO, CA 92155

COMMANDER SEVENTH FLEET
FPO SAN FRANCISCO, CA 96601

COMMANDER THIRD FLEET
PEARL HARBOR, HI 96860

COMMANDER, AMPHIBIOUS GROUP TWO
ATTN: N33
FPO NEW YORK 09501

COMMANDER TRAINING COMMAND
U.S. PACIFIC FLEET
SAN DIEGO, CA 92147

COMMANDER
NAVAL AIR DEVELOPMENT CENTER
ATTN: CODE 60B (DeSIMONE)
WARMINSTER, PA 18974

COMMANDER
NAVAL WEAPONS CENTER
CODE 4071
CHINA LAKE, CA 93555

NAVAL SURFACE WEAPONS CENTER
CODE G50 (MR. CULBERTSON)
CODE H31
CODE H31 (MR. YENCHA)
DAHLGREN, VA 22448

COMMANDING OFFICER
NAVAL RESEARCH LABORATORY
CODE 5082 (R.A. LAMONTAGNE)
CODE 6182 (TAYLOR)
WASHINGTON, DC 20375-5000

COMMANDER
NAVAL FACILITIES ENGINEERING COMMAND
CODE 0621E (T.C. ALDRIDGE)
220 STOVALL STREET
ALEXANDRIA, VA 22332

COMMANDING OFFICER
NAVAL CIVIL ENGINEERING LABORATORY
CODE LOSAB (LAMBIOTTI)
PORT HUENEME, CA 93043

HUMAN FACTORS LABORATORY
ATTN: J. DRISKELL
NAVAL TRAINING EQUIPMENT CENTER
ORLANDO, FL 32813

COMMANDING OFFICER
NAVAL TRAINING SYSTEMS CENTER
CODE N712 (R. CARSON)
ORLANDO, FL 32813

NAVAL INTELLIGENCE SUPPORT CENTER
ATTN: DA-3112
CODE 433
4301 SUITLAND ROAD
SUITLAND, MD 20390-5140

COMMANDER
NR RADCWERTLANT 108
ATTN: NMCRC
12 MEADOW STREET
CHATTANOOGA, TN 37405

COMMANDANT U.S. MARINE CORPS
ATTN: POG-31
APW
ROOM 2318 ARLINGTON ANNEX
ARLINGTON, VA 20380

COMMANDING GENERAL
FLEET MARINE FORCES PACIFIC
CAMP H.M. SMITH, HI 96861

USMC DEVELOPMENT AND EDUCATION COMMAND
DEVELOPMENT CENTER
ATTN: DO91/NBC (MAJOR POTOCKI)
DOS
QUANTICO, VA 22134

USMC LIAISON OFFICER TO TECOM
ATTN: AMSTE-ML
ABERDEEN PROVING GROUND, MD 21005

* * * * *

DIRECTOR
CENTERS FOR DISEASE CONTROL
ATTN: LOGGING CONTROL OFFICER - 1/B413
(for ASST DIR, EDWIN K. GRAY)
ATLANTA, GA 30333

COMMANDER
2ND INFANTRY DIVISION
ATTN: EAID-CM
APO SAN FRANCISCO 96224-0289

BATTELLE - EDGEWOOD OPERATIONS
ATTN: F.T. CRIMMINS, DIR CBIAC
2113 EMMORTON PARK ROAD
EDGEWOOD, MD 21040

25TH INFANTRY DIVISION
ATTN: APVG-PC-CM
SCHOFIELD BARRACKS, HI 96857-6000

ADMINISTRATOR
DEFENSE TECHNICAL INFORMATION CENTER (2 copies)
CAMERON STATION
ALEXANDRIA, VA 22314

COMMANDER
U.S. ARMY DUGWAY PROVING GROUND
ATTN: STEDP-SD-TA (2 copies)
STEDP-SD-TA-F (6 copies)
STEDP-MT-TM-CB
DUGWAY, UTAH 84022-5000



DEPARTMENT OF THE ARMY
US ARMY RESEARCH, DEVELOPMENT AND ENGINEERING COMMAND
EDGEWOOD CHEMICAL BIOLOGICAL CENTER
5183 BLACKHAWK ROAD
ABERDEEN PROVING GROUND, MD 21010-5424

REPLY TO
ATTENTION OF

RDCB-DPS-RS

MEMORANDUM THRU Director, Edgewood Chemical Biological Center, (RDCB-D/Mr. Joseph Wienand), 5183 Blackhawk Road, Aberdeen Proving Ground, Maryland 21010-5424

JC
14 OCT 14

FOR Defense Technical Information Center, 8725 John J. Kingman Road, Ft Belvoir, VA 22060

SUBJECT: Internal Request for Change in Distribution

1. This action is in response to an Edgewood Chemical Biological Center (ECBC) Internal Request for a Change in Distribution on documents related to chemical detectors.
2. The listed documents in the attachment have been reviewed by ECBC Subject Matter Experts and deemed suitable for the change in distribution to read "Approved for Public Release; distribution unlimited."
3. The point of contact is Adana Eilo, ECBC Security Specialist, (410) 436-2063 or adana.l.eilo.civ@mail.mil.

Encl

NANCY CARTER
Acting Security and Surety Manager

Chemical Detector References

- [1] Katzoff, Lionel and Razulis, Marie, Technical Report March 1981 – September 1983, CRDEC-TR-86041, "Engineering Development of the Simulator, Detector Tickets, Chemical Agent: Training M256 (TRAINS), June 1986, UNCLASSIFIED, Distribution B, U.S. Gov't Agencies Only.
- [2] Eckhaus, Robert, Technical Report May 1981-June 1984, CRDEC-TR-87054, "Product Improvement Program to Increase the Nerve Agent Sensitivity of the M256 Chemical Agent Detector Kit," June 1987, UNCLASSIFIED, Distribution B, U.S. Gov't Agencies Only.
- [3] Ramachandran, C.K., Technical Report February 1988, DPG/TA-88/07, "Reliability of M256 Chemical Agent Detector Kit at Extreme Environmental Temperatures," February 1988, UNCLASSIFIED, Distribution B, U.S. Gov't Agencies Only.
- [4] Schwartz, Laura W., Packard, Michael T., Holmes, Celestine T., and McDowell, Charles J., Technical Report April-November 1971, ED-TR-74018, "Evaluation of M15/M18 Enzyme Detector Ticket System with Concentrations of GB, June 1974, UNCLASSIFIED, Distribution C, U.S. Gov't Agencies/Contractors.